

# eliwell


by **Schneider** Electric

## IDPanel 978

User manual

9MA10274.01 06/18

Instructions translated from the original



## Information ownership

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor Eliwell nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric or Eliwell, given in writing. You also agree not to establish any hypertext links to this document or its content. Either Schneider Electric or Eliwell does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an “as is” basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Eliwell software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2018 Eliwell. All Rights Reserved.

# Contents

Safety information .....	4
About the book.....	8
Receipt, handling and storage .....	10
Storage and handling.....	10
Product identification.....	11
Description of the equipment .....	12
General description.....	12
Inputs and outputs .....	13
Parameters.....	14
Applications.....	15
Installation of the equipment.....	20
Installation warnings .....	20
Install IDPanel 978.....	21
Installer procedure .....	26
Use of the equipment.....	29
Operator procedures.....	29


Maintenance.....	32
Maintenance warnings .....	32
Controller maintenance.....	33
Routine maintenance .....	37
Diagnostics.....	38
Alarms .....	38
Troubleshooting.....	42
Assistance.....	42
Technical data .....	44
Technical specifications .....	44
Electrical connections .....	47
User parameter table .....	52
Installer parameter table .....	54
Enclosures .....	61
Single-phase version annexes.....	61
Three-phase version annexes .....	66
Drilling template .....	71


# Safety information

---

## Important information

Read these instructions carefully and visually inspect the equipment to familiarise yourself with the device before attempting to install it, put it into operation, overhaul or service it. The following warning messages may appear anywhere in this documentation or on the equipment to warn of potential dangers or to call attention to information that can clarify or simplify a procedure.

 The addition of this symbol to a danger warning label indicates the existence of an electrical danger that could result in personal injury should the user fail to follow the instructions.

 This is the safety warning symbol. It is used to warn the user of the potential dangers of personal injury. Observe all the safety warnings accompanied by this symbol to avoid the risk of serious injury or death.

## **DANGER**

**DANGER** indicates a dangerous situation that, unless avoided, **will result in death** or cause serious injuries.

## **WARNING**

**WARNING** indicates a potentially dangerous situation which, **if not avoided**, could result in death or serious injury.

## **CAUTION**

**CAUTION** indicates a potentially dangerous situation which, **if not avoided**, could result in minor or moderate injury.

## **NOTICE**

**NOTICE** used in reference to procedures not associated with physical injuries.

## **NOTE**

The electrical panel (device) must be installed and repaired by qualified personnel only. Schneider Electric and Eliwell accept no responsibility for any consequences resulting from the use of this material.

A qualified person is someone who has specific skills and knowiconge regarding the structure and the operation of electrical equipment and who has received safety training on how to avoid the inherent dangers.

## **Permitted use**

This device is used to control cold rooms in commercial refrigeration sectors.

The device must be installed and used in accordance with the instructions provided.

The device must be adequately protected from water and dust with regard to the application and the inside must only be accessible using a keyed or tooled locking mechanism.

## **Prohibited use**

Any use other than that described in the previous paragraph, Permitted Use, is strictly forbidden.

The relays supplied are electromagnetic and the contacts are subject to failure. The protection devices required by product standards, or suggested by good practice in view of obvious safety requirements, must be installed externally of the device.

## **Liability and residual risks**

The liability of Schneider Electric and Eliwell is limited to the correct and professional use of the product according to the directives referred to herein and in the other supporting documents, and does not cover any damage (including but not limited to) the following causes:

- unspecified installation/use and, in particular, in contravention of the safety requirements of established legislation or specified in this document
- use on equipment which does not provide adequate protection against electrocution, water and dust in the actual installation conditions;
- use on equipment in which dangerous components can be accessed without the use of specific tools;
- tampering and / or alteration of the product;
- installation/use on equipment which does not comply with established legislation and technical standards.

## Disposal

 The device must be subjected to separate waste collection in compliance with the local legislation on waste disposal.

## Product related information

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

- Turn off all devices, including connected devices, before removing any covers or doors, or installing/uninstalling accessories, hardware, cables, or wires.
- To check that the system is powered down, always use a voltmeter properly calibrated to the nominal voltage value.
- Before restarting the unit, replace and secure all covers, hardware accessories, cables, and check for a good ground connection.
- Use this equipment and all connected products only at the specified voltage.
- Comply with all the standards regarding accident protection and the local applicable safety directives.

**Failure to follow these instructions will result in death or serious injury.**

This equipment has been designed to operate outside of any hazardous location, and exclusive of applications that generate, or have the potential to generate, hazardous atmospheres. Only install this equipment in zones and applications known to be free, at all times, of hazardous atmospheres.

### **DANGER**

#### **POTENTIAL FOR EXPLOSION**

- Install and use this equipment in non-hazardous locations only.
- Do not install and use this equipment in applications capable of generating hazardous atmospheres, such as those applications employing flammable refrigerants.

**Failure to follow these instructions will result in death or serious injury.**

For information concerning the use of control equipment in applications capable of generating hazardous materials, consult your local, regional, or national standards bureau or certification agency.

## **⚠ WARNING**

### **INCORRECT OPERATION OF THE DEVICE**

- The signal cables (probes, digital inputs, communication, and relative power supplies) of the device must be routed separately from the power cables.
- Every implementation of this device must be tested individually and completely in order to check its proper operation before putting it in service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

# About the book

---

## Document scope

This document describes the IDPanel 978 electrical panel, including all information on installation and wiring.

Use this document to:

- install, use and maintain the electrical panel.
- connect the electrical panel to a supervisor.
- become familiar with the functions of the electrical panel.

**Note:** read this document and all related documents carefully before installing, operating or maintaining the electrical panel.

## Note regarding validity

This document is valid for the following versions of the IDPanel 978:

- Single-phase, thermal relay 5.5...8 A 230 Vac
- Single-phase, thermal relay 8...11 A 230 Vac
- Three-phase, thermal relay 3.7...5.5 A 400 Vac
- Three-phase, thermal relay 5.5...8 A 400 Vac

The technical characteristics of the devices described in this manual can also be consulted on-line. The characteristics illustrated in this manual should be identical to those which can be consulted on-line.

In line with our policy of continuous improvement, we may revise the contents to improve clarity and accuracy. If you note any discrepancies between the manual and the information consulted on-line, please use the latter as a reference.



## Related documents

Document title	Reference document code
User manual IDPanel 978 (this manual)	9MA00274.01 (IT)
	9MA10274.01 (EN)
	9MAA0274.01 (RU)
	9MAU0274.01 (AR)
IDPlus user manual	9MA00053 (IT)
	9MA10053 (EN)
Schneider Electric component documentation	see <a href="https://www.schneider-electric.com">https://www.schneider-electric.com</a>

You can download these technical publications and other technical information from our website at: [www.eliwell.com](http://www.eliwell.com)

# Receipt, handling and storage

---

## Storage and handling

### Warnings

<b><i>NOTICE</i></b>
----------------------

<b>INOPERABLE DEVICE</b>
--------------------------

- |  |
|--|
| <ul style="list-style-type: none"><li>• Consult the manufacturer and check the warranty conditions if the product must be stored for long periods.</li><li>• Protect the panel appropriately from humidity, vibrations and knocks.</li><li>• Check that all the cables are inside the box and that the cover is closed and locked.</li></ul> |
|--|

<b>Failure to follow these instructions can result in equipment damage.</b>
---

### Environmental conditions


The electrical equipment is designed to withstand the effects of shipping and storage temperatures between -25 °C and +70°C (-13 and 158 °F). For temperatures beyond this range, take appropriate precautions for further protection.

See “Environmental storage conditions” on page 46.

# Product identification

## Pack contents


The following elements are supplied in the sales package:



Part	Description
A	IDPanel 978
B	Instruction manual and drilling template (this document)
C	Four screws for closing the panel cover

## Identification label

The information contained in the identification label is important for requesting assistance, maintenance or any accessories.



Part	Description
A	Product identification data (name, basic characteristics, code)
B	Reference instruction manual code (this manual)
C	Technical data
D	Reference standards
E	CE marking
F	Production data

# Description of the equipment

## General description

### Introduction


IDPanel 978 is an electrical panel including an electronic controller and electro-mechanical components for controlling both static and ventilated refrigerating units.

### Versions

IDPanel 978 is available in several versions, for controlling three-phase or single-phase electric heaters and compressors:

- Single-phase, thermal relay 5.5...8 A 230 Vac
- Single-phase, thermal relay 8...11 A 230 Vac
- Three-phase, thermal relay 3.7...5.5 A 400 Vac
- Three-phase, thermal relay 5.5...6 A 400 Vac

### Main components



Part	Description
A	IDPlus 978 electronic controller
B	Disconnecter handle
C	Main terminal board
F1	Power component protection fuse holder
KR	Relay with four change-over contacts
QS1	General disconnecter with door lock
KC1	Contactor
RTC1	Thermal relay
F2	Controller protection fuse holder

**Note:** the illustration refers to the three-phase version.

# Inputs and outputs

## Introduction

Via the controller, the IDPanel 978 manages:

- two probe inputs
- one multi-purpose input (digital or probe) DI1 / Pb3
- one digital input DI2
- four digital outputs
- one TTL serial port

The input and output configuration must be defined when configuring the panel.

## Probe input

The probe Pb1 is used for the temperature sensor to control the compressor, the probe Pb2 for the temperature sensor to control the defrost or evaporator fans.

**Note:** it is possible to connect a probe Pb3, in place of the digital input DI1.

## Digital inputs

The digital inputs can be used for:

- energy saving algorithms.
- enabling defrost
- AUX management
- door-switch
- stand-by
- external alarm
- deep cooling
- pressure switch
- HACCP alarms

**Note:** the digital input DI1 can be used as probe Pb3.

## Relay

The four digital outputs can be used to manage:

- evaporator fans
- defrosting element
- compressor
- lights/AUX
- alarm
- stand-by

Digital output 2 and digital output 3 are managed indirectly, respectively via a relay and a contactor plus a thermal relay.

## TTL serial port

The TTL serial port has the following functions:

- connect the panel to supervision systems (Televis**System** or other supervisor via Modbus communication) or connect a second digital input.  
**Note:** communication via a supervisor precludes the use of a second digital input and requires an interface module TTL-RS485 Bus**Adapter** 150 (optional).
- use the Copy Card (optional) to configure the controller.

## Parameters

### The parameters

The input and output configuration and operating logics of the controller are defined via the parameters available directly on the interface.

The controller is pre-configured with a parameters map. The map values can be edited and reset if necessary.

### Visibility of parameters

The parameters have two levels of visibility:

- **User:** parameters for basic controller configuration. They may be protected by the user password **PA1** and are given in the “User parameter table” on page 52
- **Installer:** organised in folders, including the user parameters and other parameters for advanced controller configuration. They may be protected by the installer password **PA2** and are given in the “Installer parameter table” on page 54

# Applications

## Introduction

The applications are sets of default parameters which facilitate the controller set-up. The values of the application are loaded automatically in the parameters map and can then be edited if necessary to better respond to the actual application.





## Default applications

There are four default applications (**AP1**, **AP2**, **AP3**, **AP4**), which are differentiated mainly for the configuration of the digital outputs.

Application AP1 corresponds to the factory settings.









Application	Digital output DO1 parameter H21	Digital output DO2 parameter H22	Digital output DO3 parameter H23	Digital output DO4 parameter H24	Probe Pb1	Probe Pb2	Digital input DI1
<b>AP1</b>	Evaporator fans (3)	Defrosting element (2)	Compressor (1)	Light (5)	Compressor	Evaporator	Door-switch
<b>AP2</b>	Light (5)	Defrosting element (2)	Compressor (1)	Evaporator fans (3)	Compressor	Evaporator	Door-switch
<b>AP3</b>	Light (5)	Evaporator fans (3)	Compressor (1)	Cycle inversion defrost (2)	Compressor	Evaporator	Door-switch
<b>AP4</b>	Evaporator fans (3)	Defrosting element (2)	Compressor (1)	Alarm (4)	Compressor	Evaporator	Door-switch

To know the default values of the applications for all parameters, see the “Installer parameter table” on page 54.








## Legend

Part	Description	Part	Description
 compressor	Pb1, temperature sensor for controlling the compressor	 Defrosting element <b>Note *:</b> electric defrost. <b>Note **:</b> inverse cycle defrost.	
 defrost	Pb2, temperature sensor for controlling the defrost	 Compressor	
 Door-switch		 Light	
 Evaporator fans		 Alarm	





## Controller interface



## Controller state






Resource controller	Display	Disconnect handle position	Description
On	On	ON	The controller is on in all functions (unless anomalies are reported)
On	“LOC”	ON	Push-button panel locked. The secondary functions (long press) of buttons  ,  and  are disabled and the setpoint value cannot be modified
Stand-by	“OFF”	ON	The controller is on but all utilities are disabled and no regulation is done
Off	Off	OFF	The controller is off

## Buttons

Button	Function (short press)	Function (long press)
	<ul style="list-style-type: none"> <li>• Scroll through the menu items</li> <li>• Increase the values</li> </ul>	Settable function (parameter <b>H31</b> ) Enable manual defrosting ( <b>H31=1</b> ) by default
	<ul style="list-style-type: none"> <li>• Scroll through the menu items</li> <li>• Decrease the values</li> </ul>	Settable function (parameter <b>H32</b> ) The function enables auxiliary output <b>AUX (H31=2)</b> by default
	<ul style="list-style-type: none"> <li>• Return to the higher menu level</li> <li>• Confirm the parameter value</li> </ul>	Enable standby (when not inside the menus)
	<ul style="list-style-type: none"> <li>• Confirm the commands</li> <li>• Access the “Machine Status” menu</li> <li>• Display any alarms (if present)</li> </ul>	Access the “Programming” menu

## ICONS

**Note:** when switched on the controller runs a test (lamp test) to check that the display is intact and operating correctly: the digits and the icons blink for a few seconds.

Part	Description	Part	Description
	Permanently on: reduced set on Flashing: access to installer parameters		Permanently on: alarm tripped Flashing: alarm acknowledged.
	Permanently on: compressor active Flashing: delay, a protection or a blocked start-up		Permanently on: defrost active Flashing: manual defrost activation or via digital input
	Permanently on: fans on	<b>AUX</b>	Permanently on: AUX output active Flashing: manual deep cooling activation or via digital input
<b>°C</b>	Permanently on: display the temperature in °C (parameter <b>dro</b> =0)	<b>°F</b>	Permanently on: display the temperature in °F (parameter <b>dro</b> =1)

## Menu

Two menus are available:

Menu	Function	List of folders
Machine state	Display probe values Display and/or edit the setpoint Display any alarms present	<b>AL</b> : alarms file * <b>SEt</b> : set point setting folder <b>Pb1</b> : Pb1 value folder <b>Pb2</b> : Pb2 value folder <b>Pb3</b> : Pb3 value folder ** <b>Note</b> *: present only if alarms are active. <b>Note</b> **: present only if the probe is present.
Programming:	Set the parameters	User parameters: "User parameter table" on page 52 Installer parameters: "Installer parameter table" on page 54

# Installation of the equipment

## Installation warnings

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

- The panel must only be installed by persons who are able to work in safety.
- Turn off all devices, including connected devices, before removing any covers or doors, or installing/uninstalling accessories, hardware, cables, or wires.
- To check that the system is powered down, always use a voltmeter properly calibrated to the nominal voltage value.
- Before restarting the unit, replace and secure all covers, hardware accessories, cables, and check for a good ground connection.
- Use this equipment and all connected products only at the specified voltage.
- Comply with all the standards regarding accident protection and the local applicable safety directives.

**Failure to follow these instructions will result in death or serious injury.**

This equipment has been designed to operate outside of any hazardous location, and exclusive of applications that generate, or have the potential to generate, hazardous atmospheres. Only install this equipment in zones and applications known to be free, at all times, of hazardous atmospheres.

### **DANGER**

#### **POTENTIAL FOR EXPLOSION**

- Install and use this equipment in non-hazardous locations only.
- Do not install and use this equipment in applications capable of generating hazardous atmospheres, such as those applications employing flammable refrigerants.

**Failure to follow these instructions will result in death or serious injury.**

For information concerning the use of control equipment in applications capable of generating hazardous materials, consult your local, regional or national standards bureau or certification agency.

## ⚠ WARNING

### INCORRECT OPERATION OF THE DEVICE

- The signal cables (probes, digital inputs, communication, and relative power supplies) of the device must be routed separately from the power cables.
- Every implementation of this device must be tested individually and completely in order to check its proper operation before putting it in service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

NOTE. For correct and accurate operation of the equipment, use exclusively Eliwell probes.

## Install IDPanel 978


### Installation sequence

The following sequence is suggested for installing the panel:

1. See “Prepare the panel at the bench” on page 22
2. See “Mount the panel on the wall” on page 23, and check the distances
3. See “Connect the wires” on page 23
4. See “Calibrate the thermal relay on the compressor” on page 24
5. See “Close the panel” on page 25
6. See “Configure the controller” on page 26
7. See “Check the correct operation of the panel” on page 26

Comply with the indicated distances when installing the product (see above Figure).

### Distances




## ⚠ WARNING

### INCORRECT OPERATION OF THE DEVICE


- Do not place these devices near or above any devices which could cause overheating.
- Install the device in a point that guarantees the minimum distances from all structures and adjacent equipment as indicated in this document.
- Install all equipment in conformity with the technical specifications given in the respective documentation.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**


## Prepare the panel at the bench




1. Turn the disconnector handle to OFF and open the cover.



2. Place the drilling template on the lower side of the panel.




3. Drill the holes for the cable clamps (one for power cables and one for signalling cables).




4. Drill the holes in the bottom of the panel in the marked areas.

## Mount the panel on the wall



1. Fix the panel to the wall using four screws (not supplied) suited to the wall thickness.



2. Optional. Insert the TDI 20 screw covers (not supplied).

## Connect the wires

Connect the main terminal board, the thermal relay (**RTC1**) and the disconnecter (**QS1**), referring to the data given in the “Electrical connections” on page 47. Use suitable cable/pipe clamps.


### ***NOTICE***

#### **INOPERABLE DEVICE**


If you wish to configure the utilities differently to what set in the factory settings, pay attention to the characteristics of each digital output and adapt the wiring diagram provided in annex.

**Failure to follow these instructions can result in equipment damage.**


## Calibrate the thermal relay on the compressor




1. Turn the adjusting screw on the thermal relay (**RTC1**) and set an absorption greater than that indicated on the compressor data plate.



2. Check that all the cables are inside the box, close the cover and turn the disconnecter handle to ON.




3. Check the effective absorption of the compressor with an ammeter.




4. Turn the disconnecter handle to OFF and open the cover.





5. Turn the adjusting screw on the thermal relay (**RTC1**) and set the effective absorption of the compressor.

### Close the panel




1. Check that all the cables are inside the box, close the cover and lock with the four screws provided.

## **⚡ ⚠ DANGER**

### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

Verify cable isolation is not damaged.

**Failure to follow these instructions will result in death or serious injury.**



2. Turn the disconnecter handle to ON: the controller runs the lamp test and switches on.

## Configure the controller

When powered up, the controller is configured with the values of the parameters set in AP1, see “Applications” on page 15. Configure the controller as follows:






If	Then
The actual application corresponds to the application AP1.	Check the values of all parameters and, if necessary, edit the parameters, see “Modifying the parameters” on page 31.
The actual application corresponds to applications AP2 or AP3 or AP4.	Load the correct application, see “Loading a default application” on page 26. Check the values of all parameters and, if necessary, edit the parameters, see “Modifying the parameters” on page 31.
The actual application does not correspond to a default application.	Set the parameters as required, see “Modifying the parameters” on page 31.

## Check the correct operation of the panel

Run a complete refrigeration cycle and check the correct operation of the IDPanel 978 and the correct regulation of the controlicon refrigerated unit.

## Installer procedure

### Loading a default application

1. Hold down button  and at the same time turn the disconnecter handle to ON: “AP1” appears on the display.
2. Scroll through the applications using buttons  and .
3. To select the required application press ; to cancel the operation press : if the operation was successful, the letter “y” appears, otherwise “n” appears.
4. Wait for a few seconds: the main screen appears.

### Setting communication with a supervisor

It is possible to make the IDPanel 978 communicate with a supervisor, the procedure is described below:

1. Connect the cable supplied with the BusAdapter 150 to the TTL port on the controller.
2. Set the parameters, as follows:

If	Then
If you wish to communicate with Televis <b>System</b>	In the <b>Add</b> folder, set the parameters <b>dEA</b> , <b>FAA</b> , <b>PtS = t</b> .
If you wish to communicate with a supervisor via Modbus protocol	In the <b>Add</b> folder, set the parameters <b>dEA</b> , <b>FAA</b> , <b>Pty</b> , <b>PtS = d</b> and <b>Stp</b> .

3. Connect the cable to the Bus**Adapter** 150.





## Changing the password

There are two levels of password:











- Password “PA1”: allows access to user parameters. By default the password is disabled (parameter **PS1=0**).
- Password “PA2”: allows access to installer parameters. By default the password is enabled (parameter **PS2=15**).

The procedure for changing the two passwords is described below.




### Enable password “PA1”

1. Hold down the **SET** button.
2. Scroll through the parameters with buttons  and  to view parameter **PS1** and press the **SET** button.
3. Change the value with buttons  and .
4. To confirm the value, press the **SET** key.
5. To validate the new setting, switch the controller off and back on again.




### Changing the password “PA2”

1. Hold down the **SET** button.
2. Scroll through the parameters with buttons  and  to view parameter **PA2** and press the **SET** button.
3. Set the value “15” with buttons  and  and press the **SET** button.
4. Scroll through the folders with buttons  and  to view the **diS** folder and press the **SET** button.
5. Scroll through the parameters with buttons  and  to view parameter **PS2** and press the **SET** button.
6. Change the value with buttons  and .
7. To confirm the value, press the **SET** key.
8. To validate the new setting, switch the controller off and back on again.

## Lock/unlock the controller pushbutton panel

The controller pushbutton panel can be locked. If the lock is on, the secondary functions (long press) of buttons ,  and  are disabled and the setpoint value cannot be modified. It is in any case possible to enter the “Programming” menu and modify the parameters.

### From the “Machine Status” menu

1. Press the  button: you will enter the “Machine Status” menu
2. Within two seconds, press buttons  and  at the same time.

**Note:** the procedure is the same for both locking and unlocking the pushbutton panel.

### From the “Programming” menu

To lock the pushbutton panel, set the parameter **LOC**, in the folder **diS**, **LOC = y**; to unlock **LOC = n**.



# Use of the equipment

---







## Operator procedures

### Modifying the controller state

The actions to change the controller state are described below:

- To switch on: turn the disconnect handle to ON
- To switch off: turn the disconnect handle to OFF
- To place in standby: hold down the  button
- To re-enable after standby: hold down the  button





### Setting the Set point

1. To enter the “Machine Status” menu, press the  button.
2. Scroll through the folders using buttons  and  to display the folder **SEt** and press the  button: the current setpoint value is shown.
3. To modify the value, within 15 seconds press buttons  and .

**Note:** if “LOC” appears on the display the setpoint can only be viewed but not modified.


4. To confirm the value, press the  key.

### Displaying the probes

1. To enter the “Machine Status” menu, press the  button.
2. Scroll through the folders using buttons  and  to view the folder **Pb1**, **Pb2** or **Pb3** and press the  button: the value measured by the associated probe appears.


## Managing alarms




Consider the following diagram to set the parameters managing the temperature out of tolerance warnings:









Minimum temperature alarm	Temperature $\leq$ Set + LAL *	Temperature $\leq$ LAL (LAL with sign)
Maximum temperature alarm	Temperature $\geq$ Set + HAL **	Temperature $\geq$ HAL (HAL with sign)
Reset from minimum temperature alarm condition	Temperature $\geq$ Set + LAL + AFd or $\geq$ Set - LAL + AFd (LAL < 0)	Temperature $\geq$ LAL + AFd
Reset from maximum temperature alarm condition	Temperature $\leq$ Set + HAL - AFd (HAL > 0)	Temperature $\leq$ HAL - AFd
	* If LAL is negative, Set + LAL < Set	
	** If HAL is negative, Set + HAL < Set	


## Modifying the parameters

1. To enter the “Programming” menu hold down the  button:

If	Then
If the user password is disabled (PS1 = 0)	<p>Entering the “Programming” menu, the first user parameter appears directly.</p> <p>To modify user parameters, proceed with step 2.</p> <p>To access the installer parameters, scroll through the parameters until <b>PA2</b> appears and press the  button.</p> <p>If requested, enter the password.</p> <p><b>Note:</b> if the entered password is wrong, “PA2” will appear again and the password must be entered again.</p>
If the user password is enabled (PS1 ≠ 0)	<p>Entering the “Programming” menu, “PA1” and “PA2” alternate on the display.</p> <p>To access the user parameters, select PA1 with  and enter the password</p> <p>To access the installer parameters, select PA2 with  and enter the password</p> <p><b>Note:</b> if the entered password is wrong, “PA1” or “PA2” will appear again and the password must be entered again.</p>

2. Scroll through the parameters using buttons  and .
3. Display the required parameter and press the  button.
4. Change the value with buttons  and .
5. To confirm the value, press the  key.
6. To validate the new setting, switch the controller off and back on again.

## Manually enabling the defrosting cycle

Hold down the  button: if the temperature conditions are correct, the defrost cycle will start; otherwise, the display flashes three times and the defrost cycle is interrupted.

# Maintenance

## Maintenance warnings

### General warnings

#### **DANGER**

##### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

- Any maintenance on the panel must only be performed by persons who are able to work in safety
- Turn off all devices, including connected devices, before removing any covers or doors, or installing/uninstalling accessories, hardware, cables, or wires.
- To check that the system is powered down, always use a voltmeter properly calibrated to the nominal voltage value.
- Before restarting the unit, replace and secure all covers, hardware accessories, cables, and check for a good ground connection.
- Use this equipment and all connected products only at the specified voltage.
- Comply with all the standards regarding accident protection and the local applicable safety directives.

**Failure to follow these instructions will result in death or serious injury.**

### Power supply isolation

To prevent the power from being accidentally switched back on when replacing components inside or outside the panel and during maintenance, the person responsible for the operations must proceed as follows:

- Turn the disconnect handle to OFF.
- If the works involve components outside the panel, place a padlock in the hole on the disconnect handle and place the key in a safe place.
- Place a “Maintenance in progress” warning sign.

#### **DANGER**

##### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

Do not remove or tamper with the padlock. Do not switch the power back on without authorisation.

**Failure to follow these instructions will result in death or serious injury.**



# Controller maintenance

## Replacing the controller

### Foreword

To adapt a new standard IDPlus 978 to work in the IDPanel 978, pay particular attention to the configuration of the digital outputs.


## NOTICE

### INOPERABLE DEVICE


Note down the configuration of parameters H21, H22, H23 and H24 in the controller to be replaced.

**Failure to follow these instructions can result in equipment damage.**


### Procedure




1. Turn the disconnecter handle to OFF.




2. Remove the screws and open the panel cover.




3. Remove the cables from the controller terminals. Pay attention to the original position of each cable.




4. Remove the brackets.




5. Remove the controller from the front of the panel.




6. Fit the new controller in place of the one removed.



7. Fix the controller with the brackets.



8. Reconnect the cables to the terminals.









9. Turn the disconnecter handle to ON: the controller runs the lamp test and switches on.



10. Correctly configure the controller, see “Controller maintenance” on page 33 .  
11. To validate the new configuration, switch the controller off and back on again.

## Using the Copy Card


The Copy Card is used to quickly set the parameters and is connected to the serial port (TTL).

1. Access the installer parameters, see step 1 in the procedure “Modifying the parameters” on page 31.
2. Scroll through the folders with buttons  and  to view the **FPr** folder and press the  button.
3. Scroll through the parameters with buttons  and  to view the required parameter and press the  button.

## Operations with the Copy Card

- To format the card (recommended on first use) view parameter **Fr** and press the  button.

**NOTE.** The **Fr** parameter deletes all data present and this operation cannot be reversed.

- To load the configuration parameters from the controller to the card, view parameter **UL** and press the  button.
- To download the configuration parameters from the card to the controller, connect the card to the controller with the controller switched off. When switching the controller on, the data in the card will be automatically downloaded to the controller. At the end of the lamp test, the display will show “dLy” if the operation was successful and “dLn” if not.

**Note:** after the Download, the controller will use the newly uploaded map settings.

## Resetting the default values

In the event of a malfunction or in case of need, the default values in the parameter map can be reloaded.

### ***NOTICE***

#### **INOPERABLE DEVICE**

This operation resets the controller to its initial state, returning all parameters to their default values. This means that all changes that may have been made to operating parameters will be lost.

**Failure to follow these instructions can result in equipment damage.**

1. Hold down button **SET** and at the same time turn the disconnect handle to ON: “AP1” appears on the display.
2. Select AP1 with the **SET** button; to cancel the operation press **ⓘ**: if the operation was successful, the letter “y” appears, otherwise “n” appears.
3. Wait for a few seconds: the main display screen appears.

## Routine maintenance

### Operations

After the first 20 days of operation and subsequently once a year:

Operation	Component
Tightening	Disconnect terminals ( <b>QS1</b> )
	Thermal relay terminals ( <b>RTC1</b> )

### Cleaning

Do not use abrasive products or solvents.

# Diagnosics

## Alarms

### Introduction

An alarm condition is always shown with the  icon, the buzzer and a relay (if configured).



**Note:** if alarm exclusion times have been set (see **AL** folder in the installer parameters) the alarm will not be indicated.





### Alarm operations




To silence the buzzer, press any key: the relative icon will continue to flash.

To delete the folders **HC n**, **tC n**, **bC n** and **bt n** in the folder **AL**, launch the **rES** function in folder **FnC**.


### Alarm key

Label	Description	Cause	Effects	Troubleshooting
<b>E1</b>	Probe Pb1 in error (ambient)	<ul style="list-style-type: none"><li>Measured values are outside operating range</li><li>Probe error/short-circuited/open</li></ul>	<ul style="list-style-type: none"><li>Label <b>E1</b> displayed</li><li>icon  permanently on</li><li>Relay on (if configured)</li><li>Max/min alarm regulator disabled</li><li>Compressor operation based on parameters <b>Ont</b> and "<b>Oft</b>"</li></ul>	<ul style="list-style-type: none"><li>Check the probe type (parameter <b>H00</b>)</li><li>Check the probe wiring</li><li>Replace probe</li></ul>
<b>E2</b>	Probe Pb2 in error (defrost)	<ul style="list-style-type: none"><li>Measured values are outside operating range</li><li>Probe faulty/short-circuited/open</li></ul>	<ul style="list-style-type: none"><li>Label <b>E2</b> displayed</li><li>icon  permanently on</li><li>Relay on (if configured)</li><li>The defrost cycle will end due to time-out (parameter <b>dEt</b>)</li><li>The evaporator fans will be: ON if the compressor is ON and based on parameter <b>FCO</b> if the compressor is OFF.</li></ul>	<ul style="list-style-type: none"><li>Check the probe type (parameter <b>H00</b>)</li><li>Check the probe wiring</li><li>Replace probe</li></ul>

Label	Description	Cause	Effects	Troubleshooting
<b>E3</b>	Probe Pb3 in error	<ul style="list-style-type: none"> <li>Measured values are outside operating range</li> <li>Probe error/short-circuited/open</li> </ul>	<ul style="list-style-type: none"> <li>Label <b>E3</b> displayed</li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> </ul>	<ul style="list-style-type: none"> <li>Check the probe type (parameter <b>H00</b>)</li> <li>Check the probe wiring</li> <li>Replace probe</li> </ul>
<b>AH1</b>	Pb1 HIGH temperature alarm	Value read by probe Pb1 > HAL after time of tAO. (see Alarms Management)	<ul style="list-style-type: none"> <li>Recording of label <b>AH1</b> in folder <b>AL</b></li> <li>Relay on (if configured)</li> <li>No effect on regulation.</li> </ul>	Wait for temperature value read by Pb1 to return below HAL-AFd
<b>AL1</b>	Pb1 LOW temperature alarm	Value read by Pb1 < LAL after time of tAO. (see Alarms Management)	<ul style="list-style-type: none"> <li>Recording of label <b>AL1</b> in folder <b>AL</b></li> <li>Relay on (if configured)</li> <li>No effect on regulation.</li> </ul>	Wait for temperature value read by Pb1 to return above LAL+AFd
<b>EA</b>	External alarm	Digital input activated ( <b>H11</b> = ±5)	<ul style="list-style-type: none"> <li>Recording of label <b>EA</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> <li>Regulation blocked if <b>rLO</b> = y</li> </ul>	Check and remove the external cause which triggered the alarm on the digital input.
<b>OPd</b>	Door open alarm	Activation of digital input ( <b>H11</b> = ±4) for a time greater than tdO	<ul style="list-style-type: none"> <li>Recording of label <b>OPd</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> <li>Regulator blocked</li> </ul>	<ul style="list-style-type: none"> <li>Close the door</li> <li>Delay function defined by OAO</li> </ul>
<b>Ad2</b>	Defrost due to timeout	End of defrost cycle due to timeout rather than due to defrosting end temperature being read by Pb2.	<ul style="list-style-type: none"> <li>Recording of label <b>Ad2</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> </ul>	Await next defrost cycle for automatic return to normal

Label	Description	Cause	Effects	Troubleshooting
<b>COH</b>	Overheating alarm	Pb3 exceeded the value set by parameter <b>SA3</b> .	<ul style="list-style-type: none"> <li>Recording of label <b>COH</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> <li>Regulation locked (compressor)</li> </ul>	Wait for the temperature to return to a value of SA3 (setpoint) minus dA3 (differential)
<b>nPA</b>	General pressure alarm	Activation of pressure switch alarm by general pressure switch.	<p>If the number of pressure switch activations is <math>n &lt; PEn</math>:</p> <ul style="list-style-type: none"> <li>Recording of folder <b>nPA</b> in folder <b>AL</b> with the number of pressure switch activations</li> <li>Regulation inhibited (compressor and fans)</li> </ul>	Check and remove the cause of the alarm on the digital input (Automatic Reset)
<b>PAL</b>	General pressure alarm	Activation of pressure switch alarm by general pressure switch.	<p>If the number of pressure switch activations is <math>n = PEn</math>:</p> <ul style="list-style-type: none"> <li>Label PAL displayed</li> <li>Recording of label <b>PA</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> <li>Regulation inhibited (compressor and fans)</li> </ul>	<ul style="list-style-type: none"> <li>Switch the device off and back on again</li> <li>Reset alarms by entering the functions folder and selecting the <b>rAP</b> (Manual Reset)</li> </ul>
<b>HC n</b>	Max/Min value of Pb3 when out of range ( <b>SLH...SHH</b> )	<p>Stores the Max/Min value read by Pb3 when it exceeds the range <b>SLH...SHH</b>.</p> <p>“n” represents the sequential number of times the range is exceeded.</p>	<ul style="list-style-type: none"> <li>Recording of folder <b>HC n</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> <li>No effect on regulation.</li> </ul>	<b>Note:</b> “n” can assume the values 1 to 8. If $n > 8$ , folder <b>HC8</b> will blink and the system will overwrite the folders starting from $n=1$ .



Label	Description	Cause	Effects	Troubleshooting
<b>tC n</b>	Pb3 Dwell Time out of range ( <b>SLH...SHH</b> )	Stores the time for which the Pb3 value remains outside of the range SLH...SHH.  “n” represents the sequential number of times the range is exceeded.	<ul style="list-style-type: none"> <li>Recording of folder <b>tC n</b> in folder <b>AL</b></li> <li>icon  permanently on</li> <li>Relay on (if configured)</li> <li>No effect on regulation.</li> </ul>	<b>Note:</b> “n” can assume the values 1 to 8. If n > 8, folder <b>tC8</b> will blink and the system will overwrite the folders starting from n=1.
<b>bC n</b>	Value read by Pb3 on return from blackout	Stores the value read by Pb3 on return from a blackout.  “n” represents the sequential number of blackouts that have occurred.	<ul style="list-style-type: none"> <li>Recording of folder <b>bC n</b> in folder <b>AL</b></li> <li>No effect on regulation.</li> </ul>	<b>Note:</b> “n” can assume the values 1 to 8. If n > 8, folder <b>bC8</b> will blink and the system will overwrite the folders starting from n=1.
<b>bt n</b>	Pb3 out-of-range dwell time during blackout	Stores the time for which the Pb3 value remains out of range during a blackout.  “n” represents the sequential number of blackouts that have occurred.	<ul style="list-style-type: none"> <li>Recording of folder <b>bt n</b> in folder <b>AL</b>. The value contained will be 0 if the value of Pb3 has remained within the range, ≠ 0 if the value has gone outside of the range.</li> <li>No effect on regulation.</li> </ul>	<b>Note:</b> “n” can assume the values 1 to 8. If n > 8, folder <b>bt8</b> will blink and the system will overwrite the folders starting from n=1.

# Troubleshooting

## List of possible problems

Problem	Possible causes	Solution
The compressor starts with a manual command but not a controller command	Panel not powered up.	<ul style="list-style-type: none"><li>• Check that the disconnecter is in the ON position.</li><li>• Check the disconnecter connections.</li><li>• Check the distribution line.</li></ul>
The controlon utilities do not behave as expected	Incorrect wiring to the main terminal board	Check the wiring, referring to the data given in “Electrical connections” on page 47.
	Parameters set incorrectly.	Modify the value of the parameters, see “Modifying the parameters” on page 31.
The temperature value read by the probe is not real	Probe type set incorrectly.	Set the correct probe type (parameter <b>H00</b> )

## Assistance

### How to ask for assistance

#### Customer Technical Support

+39 0437 986 300

techsuppeliwell@schneider-electric.com

#### Sales

+39 0437 986 100 (Italy)


+39 0437 986 200 (Other countries)

saleseliwell@schneider-electric.com

## How to return the equipment

In the event of a failure or malfunction which requires the equipment to be returned, return it in its original packaging to the local distributor.

Note the distributor data here:



# Technical data

## Technical specifications

### General specifications

	Single-phase versions	Three-phase versions
<b>Power supply</b>	230 Vac (F + N + PE), 50/60 Hz	400 Vac (3F + N + T), 50/60 Hz
<b>Command type</b>	Single-phase	Three-phase
<b>Disconnecter</b>	25 A	
<b>Control</b>	IDPlus 978 electronic controller	
<b>Connectivity</b>	TTL port for connection to Televis <b>System</b> /Modbus supervisor	
<b>Controller protection</b>	1 fuse, 5 x 20 mm (0.20 x 0.8 in) 160 mA, T	
<b>General protection</b>	2 fuses, 10 x 38 mm (0.40 x 1.5 in), 25 A, T. See “Single-phase version annexes” on page 61.	3 fuses (1), 10 x 38 mm (0.40 x 1.5 in), 25 A, T. See “Three-phase version annexes” on page 66.
	(1) NOTE: pay attention to the fuses insertion in the three-phase version: the fuse holder is provided with dual slot for spare fuses. The correct position is the lower one.	
<b>Motor protection</b>	See “Single-phase version annexes” on page 61.	See “Three-phase version annexes” on page 66.
<b>Enclosure rating</b>	IP54	
<b>Over voltage category</b>	II (IEC 60664-1: 2007).	
<b>Pollution class</b>	2 (IEC 60664-1: 2007).	
<b>Location type</b>	Indoor	
<b>Installation method</b>	Stationary	
<b>Max Altitude installation site</b>	2000 m	

## Electrical specifications

	Single-phase versions	Three-phase versions
Rated voltage ( $U_n$ )	230 Vac	400 Vac
Rated operating voltage ( $U_o$ )	230 Vac	400 Vac
Rated insulation voltage ( $U_i$ )	230 Vac	400 Vac
Rated panel current ( $I_{nA}$ )	15 A 18 A	5,5 A per phase + 7 A on single phase 6 A per phase + 7 A on single phase
Rated circuit current ( $I_{nC}$ )	15 A 18 A	5,5 A per phase + 7 A on single phase 6 A per phase + 7 A on single phase
Rated short-time withstand current ( $I_{cW}$ )	19 A 24 A	15 A 19 A
Rated peak withstand current ( $I_{pk}$ )	20 A 25 A	16 A 20 A
Conditioned short circuit current ( $I_{cc}$ )	< 5 kA	<5 kA
Rated frequency ( $f_n$ )	50/60 Hz	50/60 Hz

## Inputs and outputs (see “Electrical connections” on page 55)

Probe input	2 + 1 (in place of a digital input)
Digital inputs	1 (in place of a probe input) + 1 (if no communication with supervisor via the TTL port)
Digital outputs	4 relays

## Probe values

**Note:** data relating only to the IDPanel 978 without considering the probes (accessories not supplied). The error introduced by the probe must be added to the values given here.

<b>Display range</b>	3 figures + sign NTC: -50.0...110 °C (-58...230 °F) PTC: -55.0...140 °C (-67...284 °F) Pt1000: -55.0...150 °C (-67...302 °F)
<b>Accuracy</b>	NTC/PTC/Pt1000 (-55.0...70 °C/-67...158 °F): 0.5% better than the integral scale + 1 digit Pt1000 (70...150 °C/158...302 °F): 0.6% better than the integral scale + 1 digit
<b>Resolution</b>	0.1 °C (1 °F)

## Mechanical characteristics

	Single-phase versions	Three-phase versions
<b>Material</b>	PC + ABS	
<b>Installation</b>	On wall	
<b>Size (L x H x P)</b>	213 x 318 x 102 mm (8.4 x 12.5 x 4 in)	
<b>Weight</b>	3 kg (6.6 lb)	


## Ambient conditions of use

<b>Temperature</b>	-5...+40 °C (23...+104 °F)	according to IEC 61439-2, for indoor use
<b>Humidity</b>	10...90% without condensation	

## Transportation and storage conditions

<b>Temperature</b>	-25...+70 °C (-13...+158 °F)
<b>Humidity</b>	10...90% without condensation

## Standards and directives

<b>Directives</b>	2014/35/EU (Low voltage) 2014/30/EU (Electro-magnetic compatibility)
<b>Standards</b>	EN 60204-1 EN 61439-1
<b>Marking</b>	

## Electrical connections

  **DANGER**

### HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

The electrical connections must only be made by persons who are able to work in safety.

**Failure to follow these instructions will result in death or serious injury.**

## Wiring diagram

### ***NOTICE***

#### **INOPERABLE DEVICE**


The wiring diagram refers to the factory configuration. If during installation a different configuration is defined, the installer must update the wiring diagram.

**Failure to follow these instructions can result in equipment damage.**

For single-phase versions, see “Single-phase version wiring diagram” on page 61.

For three-phase versions, see “Three-phase version wiring diagram” on page 66.

## Main terminal board



**Note:** use the **PE** terminals to connect the system to earth.

Terminal	Description	Features	Cables
XV-L	Digital output 1 (Evaporator fans)	250 Vac (1-PH) 10(6) A	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG) Flexible wire section: 0.08...2.5 mm <sup>2</sup> (28...14 AWG)
XV-N			
PE			
XR-L1	Digital output 2 (Electrical defrosting element)	Single-phase versions: 800 W Three-phase versions: 1200 W	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG) Flexible wire section: 0.08...2.5 mm <sup>2</sup> (28...14 AWG)
XR-L2			
XR-L3			
XR-N			
PE			



Terminal	Description	Features	Cables
<b>X1-1</b>	Digital output 4 (Light)	250 Vac (1-ph) 8(4) A	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>X1-2</b>			Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>X1-3</b>	Not used	-	-
<b>X1-4</b>			
<b>XP-1</b>	Pressure switch input	230 Vac  For single-phase models see “Single-phase version wiring diagram” on page 61  For three-phase models see “Three-phase version wiring diagram” on page 66	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XP-2</b>			Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XS-1</b>	Probe Pb1  (Temperature sensor for controlling the compressor)	NTC (default)/PTC/Pt1000  (configurable by parameter H00)	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XS-2</b>			Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XS-3</b>	Probe Pb2  (Temperature sensor for controlling the defrosting cycle)	NTC (default)/PTC/Pt1000  (configurable by parameter H00)	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XS-4</b>			Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XDI1-1</b>	Digital input DI1/Probe Pb3 (Door- switch)	SELV	Solid wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)
<b>XDI1-2</b>			Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)


## Disconnecter - QS1 (single-phase versions)

	Terminal	Description	Features	Cables	Tightening
	1L1	Stage	See "General characteristics" on page 44	Solid wire section: 0.75 mm <sup>2</sup> (18 AWG) Flexible wire section: 10 mm <sup>2</sup> (8 AWG)	1 Nm (8.9 lb-in)
	5L3	Neutral			
			Ground	-	Solid wire section: 0.08...6 mm <sup>2</sup> (28...10 AWG) Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)

## Disconnecter - QS1 (three-phase versions)

	Terminal	Description	Features	Cables	Tightening
	1L1	Phase 1	See "General characteristics" on page 44	Solid wire section: 0.75 mm <sup>2</sup> (18 AWG) Flexible wire section: 10 mm <sup>2</sup> (8 AWG)	1 Nm (8.9 lb-in)
	3L2	Phase 2			
	5L3	Phase 3			
	(N) 7L4	Neutral			
			Ground	-	Solid wire section: 0.08...6 mm <sup>2</sup> (28...10 AWG) Flexible wire section: 0.08...4 mm <sup>2</sup> (28...12 AWG)


## Thermal relay (RTC1)

	Terminal	Description	Features	Cables	Tightening
	2T1	Digital output 3 (Compressor)	Single-phase versions:	Screw clamp terminals 2 cable(s) 0.34...1.5 mm <sup>2</sup> (22...15 AWG)	1.3 Nm (11.5 lb-in)
	4T2		Three-phase versions:	cable stiffness: flexible – with cable end	
	6T3		Screw clamp terminals 1 cable(s) 0.34...2.5 mm <sup>2</sup> (22...14 AWG)		
		cable stiffness: flexible – with cable end			
		Screw clamp terminals 2 cable(s) 0.75...4 mm <sup>2</sup> (18...12 AWG)			
		cable stiffness: flexible – without cable end			
		Screw clamp terminals 1 cable(s) 0.75...4 mm <sup>2</sup> (18...12 AWG)			
		cable stiffness: flexible – without cable end			
		Screw clamp terminals 2 cable(s) 1.5...4 mm <sup>2</sup> (16...12 AWG)			
		cable stiffness: solid			
		Screw clamp terminals 1 cable(s) 1.5...4 mm <sup>2</sup> (16...12 AWG)			
		cable stiffness: solid			

## Controller TTL serial port

### TTL

TTL (Molex 5268) for connection to the Copy Card (maximum length = 3 m - 9.8 ft.)



## Connection to the supervisor

Use only the cable supplied with the interface module TTL-RS485 BusAdapter 150.

## Digital input 2 connection

Use terminals 1 and 2 on the TTL connector: (see figure)

## User parameter table

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
<b>SEt</b>	Temperature control setpoint	LSE ... HSE	0.0	0.0	0.0	0.0	°C/°F
<b>diF</b>	Compressor relay activation differential	0.1 ... 30.0	2.0	2.0	2.0	2.0	°C/°F
<b>HSE</b>	Maximum value settable for setpoint	LSE ... 302	99.0	99.0	99.0	99.0	°C/°F
<b>LSE</b>	Minimum value settable for setpoint	-58.0 ... HSE	-50.0	-50.0	-50.0	-50.0	°C/°F
<b>dtY</b>	Type of defrost <b>0</b> = electrical defrost; <b>1</b> = inverse cycle defrost; <b>2</b> = defrost independent of compressor.	0/1/2	0	0	1	0	num
<b>dit</b>	Interval between the start of two consecutive defrost cycles	0 ... 250	6	6	6	6	hours
<b>dEt</b>	Defrost timeout	1 ... 250	30	30	30	30	min
<b>dSt</b>	Defrost end temperature	-50.0 ... 150	8.0	8.0	8.0	8.0	°C/°F
<b>FSt</b>	Fans disabling temperature	-58.0 ... 302	50.0	50.0	50.0	50.0	°C/°F
<b>Fdt</b>	Fans on delay after a defrost cycle	0 ... 250	2	2	2	2	min
<b>dt</b>	Dripping time	0 ... 250	1	1	1	1	min
<b>dFd</b>	Used to exclude the fans or not (depending on the parameter <b>FCO</b> ) <b>n</b> (0) = no (depending on the parameter <b>FCO</b> ); <b>y</b> (1) = yes (fan off).	n/y	y	y	y	y	flag
<b>HAL</b>	Maximum temperature alarm	LAL ... 150	50.0	50.0	50.0	50.0	°C/°F
<b>LAL</b>	Minimum temperature alarm	-50.0 ... HAL	-50.0	-50.0	-50.0	-50.0	°C/°F
<b>LOC</b>	Basic commands edit lock <b>n</b> (0) = no; <b>y</b> (1) = yes.	n/y	n	n	n	n	flag

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
PS1	Password 1 to access the parameters in the "QUICK" menu	0 ... 250	0	0	0	0	num
CA1	Calibration1. Value to be added to the value read by Pb1	-12.0 ... 12.0	0.0	0.0	0.0	0.0	°C/°F
CA2	Calibration2. Value to be added to the value read by Pb2	-12.0 ... 12.0	0.0	0.0	0.0	0.0	°C/°F
CA3	Calibration3. Value to be added to the value read by Pb3	-12.0 ... 12.0	0.0	0.0		0.0	°C/°F
ddL	Display mode during defrost  0 = shows the temperature read by Pb1; 1 = locks the reading on the value of Pb1 at the start of defrost; 2 = shows the label "dEF".	0/1/2	0	0	0	0	num
Ldd	Display lock disabling time-out. 0 = function disabled	0 ... 255	30	30	30	30	min
SHH	Maximum HACCP alarm signals threshold	-55.0 ... 150	50.0	50.0	50.0	50.0	°C/°F
SLH	Minimum HACCP alarm signals threshold	-55.0 ... 150	-50.0	-50.0	-50.0	-50.0	°C/°F
drA	Minimum dwelling time in critical area before alarm	0 ... 99	0	0	0	0	min
drH	HACCP alarm reset time from last reset	0 ... 250	72	72	72	72	hours
H50	Enable HACCP and alarm relay functions  0 = HACCP alarms NOT enabled; 1 = HACCP alarms enabled and alarm relay NOT enabled; 2 = HACCP enabled and alarm relay enabled.	0/1/2	0	0	0	0	num
H51	HACCP alarm override time	0 ... 250	0	0	0	0	min
H42	Evaporator probe present	n/y	y	y	y	y	flag
H43	Probe Pb3 present	n/y	n	n	n	n	flag
rEL	rELease firmware. Reserved: read-only parameter	/	/	/	/	/	/
tAb	tAble of parameters. Reserved: read-only parameter	/	/	/	/	/	/
PA2	Access to installer parameters	/	/	/	/	/	/

## Installer parameter table

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
<b>SEt</b>	Temperature control setpoint.	LSE ... HSE	0.0	0.0	0.0	0.0	°C/°F
<b>COMPRESSOR (folder "CP")</b>							
<b>diF</b>	Compressor relay activation differential.	0.1...30.0	2.0	2.0	2.0	2.0	°C/°F
<b>HSE</b>	Maximum value that can be assigned to the setpoint.	LSE...302	99.0	99.0	99.0	99.0	°C/°F
<b>LSE</b>	Minimum value that can be assigned to the setpoint.	-58.0...HSE	-50.0	-50.0	-50.0	-50.0	°C/°F
<b>OSP</b>	Temperature value to be added to the setpoint if reduced set enabled (Economy Function).	-30.0...30.0	3.0	3.0	3.0	3.0	°C/°F
<b>Hc</b>	Regulation method. <b>C</b> = Cold; <b>hours</b> = Hot.	C/hours	C	C	C	C	flag
<b>Ont</b>	Controller switch-on time in the event of faulty probe. If <b>Ont</b> = 1 and <b>OFt</b> = 0 the compressor remains on continuously; if <b>Ont</b> =1 and <b>OFt</b> >0 it operates in duty cycle mode.	0 ... 250	15	15	15	15	min
<b>OFt</b>	Controller switch-off time in the event of faulty probe. If <b>OFt</b> = 1 and <b>Ont</b> = 0 the controller remains off continuously; if <b>OFt</b> = 1 and <b>Ont</b> > 0 it operates in duty cycle mode.	0 ... 250	15	15	15	15	min
<b>dOn</b>	Compressor relay activation delay after request.	0 ... 250	0	0	0	0	s
<b>dOF</b>	Delay after switching off and subsequent switch-on.	0 ... 250	0	0	0	0	min
<b>dbi</b>	Delay between two consecutive compressor switch-ons.	0 ... 250	0	0	0	0	min
<b>Odo</b>	Delay in activating outputs after the controller is switched on or after a power failure. <b>0</b> = not active. <b>Note:</b> if this parameter is modified, the controller MUST be switched off and then switched back on to make the modification effective.	0 ... 250	0	0	0	0	min
<b>dCS</b>	"Blast Chilling" setpoint.	-58.0...302	0.0	0.0	0.0	0.0	°C/°F
<b>tdc</b>	"Blast Chilling" duration.	0 ... 255	0	0	0	0	min
<b>dcc</b>	Defrost activation delay after a "Blast Chilling Cycle".	0 ... 255	0	0	0	0	min



PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
<b>DEFROST (folder "dEF")</b>							
<b>dtY</b>	Type of defrost <b>0</b> = electrical defrost; <b>1</b> = inverse cycle defrost; <b>2</b> = defrost independent of compressor.	0/1/2	0	0	1	0	num
<b>dit</b>	Interval between the start of two consecutive defrost cycles.	0 ... 250	6	6	6	6	hours
<b>dCt</b>	Selects the count mode for the defrost interval. <b>0</b> = hours of compressor operation; <b>1</b> = hours of equipment operation; <b>2</b> = at each compressor stop a defrost cycle is run.	0/1/2	1	1	1	1	num
<b>dOH</b>	Delay preceding start of first defrost after call.	0 ... 59	0	0	0	0	min
<b>dEt</b>	Defrost time-out; determines the maximum defrost duration.	1 ... 250	30	30	30	30	min
<b>dSt</b>	Defrost end temperature - determined by probe Pb2.	-50.0...150	8.0	8.0	8.0	50.0	°C/°F
<b>dPO</b>	Determines whether or not the instrument must defrost at power-up. <b>n</b> (0) = no; <b>y</b> (1) = yes.	n/y	n	n	n	n	flag
<b>FANS (folder "FAn")</b>							
<b>FSt</b>	Fans disabling temperature.	-58.0...+302	50.0	50.0	50.0	50.0	°C/°F
<b>FAd</b>	Fan activation differential.	1.0 ... 50.0	2.0	2.0	2.0	2.0	°C/°F
<b>Fdt</b>	Fan activation delay after a defrost cycle.	0 ... 250	2	2	2	2	min
<b>dt</b>	Dripping time.	0 ... 250	1	1	1	1	min
<b>dFd</b>	Allows exclusion of the evaporator fans to be selected or not selected during defrosting. <b>n</b> (0) = no (depending on the parameter <b>FCO</b> ); <b>y</b> (1) = yes (fan off).	n/y	y	y	y	y	flag
<b>FCO</b>	Selects or deselects fan deactivation at compressor OFF. <b>0</b> = fans off; <b>1</b> = thermostat-controlicon fans; <b>2</b> = duty cycle.	0/1/2	0	0	0	0	num
<b>FOn</b>	Time fans remain ON during daytime duty cycle.	0 ... 99	0	0	0	0	min
<b>FOF</b>	Time fans remain OFF during daytime duty cycle	0 ... 99	0	0	0	0	min
<b>Fnn</b>	Time fans remain ON during night-time duty cycle.	0 ... 99	0	0	0	0	min
<b>FnF</b>	Time fans remain OFF during night-time duty cycle.	0 ... 99	0	0	0	0	min

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
ESF	"Night" activation mode. <b>n</b> (0) = no; <b>y</b> (1) = yes.	n/y	n	n	n	n	flag
<b>ALARMS (folder "AL")</b>							
Att	Can be used to select if parameters <b>HAL</b> and <b>LAL</b> have absolute ( <b>Att</b> = 0) or relative value ( <b>Att</b> = 1).	0/1	0	0	0	0	flag
AFd	Alarm differential.	1.0 ... 50.0	2.0	2.0	2.0	2.0	°C/°F
HAL	Maximum temperature alarm.	LAL...302	50.0	50.0	50.0	50.0	°C/°F
LAL	Minimum temperature alarm.	-58.0...HAL	-50.0	-50.0	-50.0	-50.0	°C/°F
PAO	Alarm exclusion time on switching back on after power failure.	0 ... 10	1	1	1	1	hours
dAO	Temperature alarm exclusion time after defrost.	0 ... 999	15	15	15	15	min
OA0	Alarm signalling delay after digital input disabling.	0 ... 10	1	1	1	1	hours
tdO	Door open alarm activation delay.	0 ... 250	15	15	15	15	min
tAO	Delay preceding temperature alarm signal.	0 ... 250	0	0	0	0	min
dAt	Alarm signalling end of defrost due to timeout. <b>n</b> (0) = no; <b>y</b> (1) = yes.	n/y	n	n	n	n	flag
rLO	An external alarm locks the regulators. <b>n</b> (0) = does not lock; <b>y</b> (1) = locks	n/y	n	n	n	n	flag
SA3	Probe Pb3 alarm Setpoint.	-58.0...302	50.0	50.0	50.0	50.0	°C/°F
dA3	Probe Pb3 alarm differential.	1.0 ... 50.0	1.0	1.0	1.0	1.0	°C/°F
<b>LIGHTS &amp; DIGITAL INPUTS (folder "Lit")</b>							
dOd	Digital input for switching off utilities. <b>0</b> = disabled; <b>1</b> = fans disabled; <b>2</b> = compressor disabled; <b>3</b> = fans and compressor disabled.	0/1/2/3	3	3	3	3	num
dAd	Activation delay for digital input.	0 ... 255	0	0	0	0	min
dCO	Delay in deactivating compressor after door opened.	0 ... 255	1	1	1	1	min



PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
<b>AuP</b>	AUX relay associated to door-switch. n (0) = not associated; y (1) = associated.	n/y	n	n	n	n	flag
<b>PRESSURE SWITCH (folder "PrE")</b>							
<b>Pen</b>	Number of errors allowed per generic pressure switch input.	0 ... 15	0	0	0	0	num
<b>PEI</b>	Generic pressure switch error count interval.	1 ... 99	1	1	1	1	min
<b>PEt</b>	Delay in activating compressor after pressure switch deactivation.	0 ... 255	0	0	0	0	min
<b>COMMUNICATION (folder "Add")</b>							
<b>PtS</b>	Selection of communication protocol. t (0) = Televis; d (1) = Modbus.	t/d	t	t	t	t	flag
<b>dEA</b>	Index of the device within the family (valid values from 0 to 14).	0 ... 14	0	0	0	0	num
<b>FAA</b>	Device family (valid values from 0 to 14).	0 ... 14	0	0	0	0	num
<b>Pty</b>	Modbus parity bit. n (0) = none; E (1) = even; o (2) = odd.	n/E/o	n	n	n	n	num
<b>StP</b>	Modbus stop bit. 1b (0) = 1 bit; 2b (1) = 2 bit.	1b/2b	1b	1b	1b	1b	flag
<b>DISPLAY (folder "diS")</b>							
<b>LOC</b>	Basic commands edit lock. It is still possible to access parameter programming and edit the parameters. n (0) = no; y (1) = yes.	n/y	n	n	n	n	flag
<b>PS1</b>	Password1: if PS1≠0 it is the password to the user parameters	0 ... 250	0	0	0	0	num
<b>PS2</b>	Password2: if PS2≠0 is the access key to the installer parameters	0 ... 250	15	15	15	15	num
<b>ndt</b>	Display with decimal point. n (0) = no; y (1) = yes.	n/y	y	y	y	y	flag
<b>CA1</b>	Calibration 1. Temperature value to be added to the value of Pb1.	-12.0...12.0	0.0	0.0	0.0	0.0	°C/°F
<b>CA2</b>	Calibration 2. Temperature value to be added to the value of Pb2.	-12.0...12.0	0.0	0.0	0.0	0.0	°C/°F

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
<b>CA3</b>	Calibration 3. Temperature value to be added to the value of Pb3.	-12.0...12.0	0.0	0.0	0.0	0.0	°C/°F
<b>ddL</b>	Display mode during defrost. <b>0</b> = shows the temperature read by Pb1; <b>1</b> = locks the reading on the value of Pb1 at the start of defrost; <b>2</b> = shows the label “dEF”.	0/1/2	0	0	0	0	num
<b>Ldd</b>	Timeout value for display unlock - label “dEF”.	0 ... 255	30	30	30	30	min
<b>dro</b>	Select the unit of measurement used when displaying the temperature recorded by the probes. <b>0</b> = °C, <b>1</b> = °F. <b>Note:</b> switching between °C and °F DOES NOT modify the SET, diF etc. values. (for examp setpoint=10°C becomes 10 °F)	0/1	0	0	0	0	flag
<b>ddd</b>	Selects the type of value to show in the display. <b>0</b> = Setpoint; <b>1</b> = probe Pb1; <b>2</b> = probe Pb2; <b>3</b> = probe Pb3.	0/1/2/3	1	1	1	1	num
<b>HACCP (folder “HCP”)</b>							
<b>SHH</b>	Maximum HACCP alarm signals threshold.	-55.0...150	50.0	50.0	50.0	50.0	°C/°F
<b>SLH</b>	Minimum HACCP alarm signals threshold.	-55.0...150	-50.0	-50.0	-50.0	-50.0	°C/°F
<b>drA</b>	Minimum dwelling time in critical area for the event to be recorded. After this time a HACCP alarm will be logged and signalicon.	0 ... 99	0	0	0	0	min
<b>drH</b>	HACCP alarm reset time from last reset.	0 ... 250	72	72	72	72	hours
<b>H50</b>	Enable HACCP and alarm relay functions. <b>0</b> = HACCP alarms NOT enabled; <b>1</b> = HACCP alarms enabled and alarm relay NOT enabled; <b>2</b> = HACCP enabled and alarm relay enabled.	0/1/2	0	0	0	0	num
<b>H51</b>	HACCP alarm override time.	0 ... 250	0	0	0	0	min
<b>CONFIGURATION (Folder “CnF”)</b>							
<b>Note:</b> if at least one parameter in this folder is modified, the controller MUST be switched off and then switched back on to make the modification effective.							
<b>H00</b>	Probe type selection. 0 = PTC; 1 = NTC; 2 = Pt1000.	0/1/2	1	1	1	1	num

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
H11	Configuration of digital input DI1/polarity. <b>0</b> = disabled; <b>±1</b> = defrost; <b>±2</b> = reduced set; <b>±3</b> = AUX; <b>±4</b> = door-switch; <b>±5</b> = external alarm; <b>±6</b> = standby; <b>±7</b> = pressure switch; <b>±8</b> = deep cooling; <b>±9</b> = disable HACCP alarm logging. <b>Note:</b> the “+” sign indicates the input is active when the contact is closed; the “-” sign indicates that the input is active when the contact is opened	-9 ... +9	4	4	4	4	num
H12	Configuration of digital input 2/polarity. Same as H11.	-9 ... +9	0	0	0	0	num
H21	Configurability of digital output 1. <b>0</b> = disabled; <b>1</b> = compressor; <b>2</b> = defrost; <b>3</b> = fans; <b>4</b> = alarm; <b>5</b> = AUX; <b>6</b> = standby.	0 ... 6	3	5	5	3	num
H22	Configurability of digital output 2. Same as H21.	0 ... 6	2	2	3	2	num
H23	Configurability of digital output 3. Same as H21.	0 ... 6	1	1	1	1	num
H24	Configurability of digital output 4. <b>0</b> = disabled; <b>1</b> = compressor; <b>2</b> = defrosting; <b>3</b> = fans; <b>4</b> = alarm; <b>5</b> = AUX; <b>6</b> = standby; <b>7</b> = not used.	0 ... 7	5	3	2	4	num
H25	Enable/disable buzzer. <b>0</b> = Disabled; <b>4</b> = Enabled; <b>1-2-3-5-6-7-8</b> = not used.	0 ... 8	4	4	4	4	num
H31	Key configurability  <b>0</b> = disabled; <b>1</b> = defrosting; <b>2</b> = AUX; <b>3</b> = reduced set; <b>4</b> = standby; <b>5</b> = reset HACCP alarms; <b>6</b> = HACCP alarms disabled; <b>7</b> = deep cooling.	0 ... 7	1	1	1	1	num
H32	Configurability button  . Same as H31.	0 ... 7	2	2	2	0	num
H42	Evaporator probe present. <b>n</b> (0) = not present; <b>y</b> (1) = present.	n/y	y	y	y	y	flag
H43	Probe 3 present. <b>n</b> (0) = not present; <b>y</b> (1) = present.	n/y	n	n	n	n	flag
rEL	Reserved: read-only parameter. Device version.	/	-	-	-	-	-

PARA.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
<b>tAb</b>	Reserved: read-only parameter. Table of parameters.	-	-	-	-	-	-
<b>COPY CARD (folder "FPr")</b>							
<b>UL</b>	Transfer of programming parameters from instrument to Copy Card	-	-	-	-	-	-
<b>Fr</b>	Format Copy Card. To erase all data on the Copy Card. <b>Note:</b> if parameter "Fr" is used, the data entered will be permanently lost. This operation cannot be reversed.	-	-	-	-	-	-
<b>Functions (folder "FnC")</b>							
<b>rAP</b>	Reset pressure switch alarms.	-	-	-	-	-	-
<b>rES</b>	Reset HACCP alarms.	-	-	-	-	-	-

# Enclosures

---

## Single-phase version annexes


### Single-phase version wiring diagram

#### ***NOTICE***



##### **INOPERABLE DEVICE**

The wiring diagram refers to the factory configuration. If during installation a different configuration is defined, the installer must update the wiring diagram.

**Failure to follow these instructions can result in equipment damage.**



# Single-phase version topography









## Three-phase version annexes


### Three-phase version wiring diagram

#### ***NOTICE***

##### **INOPERABLE DEVICE**

The wiring diagram refers to the factory configuration. If during installation a different configuration is defined, the installer must update the wiring diagram.

**Failure to follow these instructions can result in equipment damage.**





**400VAC  
3F + N + PE**

Provide a proper safety devices equipped with differential magnetothermal switch

CODE	FUSE (F1)	RTC1	
*	10A GG	LR2K0310	2.6-3.7 A
ELP302DSX0900	16A GG	LR2K0312	3.7-5.5 A
ELP303DSX0900	20A GG	LR2K0314	5.5-8 A

\* Contact our Sales Office for availability


# Three-phase version topography







# Drilling template



**IDPanel 978**

User manual

9MA10274.01 EN 06/18

© 2018 Eliwell

**Eliwell Controls s.r.l.**

Via dell'Industria, 15 • Z.I. Paludi

32016 Alpago (BL) ITALY

T +39 0437 986 111

**[www.eliwell.com](http://www.eliwell.com)**

**Customer Technical Support**

T +39 0437 986 300

E [techsuppeliwell@schneider-electric.com](mailto:techsuppeliwell@schneider-electric.com)

**Sales**

T +39 0437 986 100 (Italy)

+39 (0) 437 986 200 (other countries)

E [saleseliwell@schneider-electric.com](mailto:saleseliwell@schneider-electric.com)