

Technical Support

Bulletin Nr. 7 – TelevisCompact



Contents

- Introduction
- Initial start-up
- Navigating the menus
- Setting the date and time
- Acquisition range
- Automatic configuration of the network
- Checking the presence of drivers –Assigning a name to controllers
- Starting/stopping recordings

Introduction


This document provides general information on how to start Televis**Compact20 & 60**. For detailed information on settings and options, please refer to the User's manual available on the CD-ROM provided with the device.

Initial start-up should be carried out following the steps outlined below and in the chronological order specified.


The following operations refer to the display and keyboard of Televis**Compact 20 & 60**.

Initial start-up

- When you first switch the device on, after a long period of time, the display may prompt you to re-enter the date and time.




- Switch the device on and off. If the message continues to display, switch the device on and off again. Menu items can be selected ONLY when the display shows the following message, which can be regarded as the "Main View":



Navigating the menus

- From the "Main View", press or to open the first menu, as shown in the figure:



- In the screen shown in the figure, press to open the remaining menus:




The available menus are: 1-Functions; 2-Recordings; 3-Devices Names; 4-Diagnostics; 5-System Info; 6-Print; 7-Programming; and 8-Setup.

- Select the desired menu and press to open it. Alternatively, press or to find the desired parameter. To display the value, press ; to close the screen, press . For more detailed information, see the following examples.


Setting date and time

Press **esc** several times to close all menus and return to the "Main View".


- From the "Main View", press **7** several times until the following displays:



- Press **enter** to open the menus. As soon as the password prompt displays, press **enter** for 5 times, then press it one last time to confirm the selection.




- Press **enter** to open Menu 1 – Clock.



- To change the display values, press **enter**. The cursor will display under the first pair of numbers ("14" in the figure). Press **4** or **2** to set the desired value, press **right** to move to the second pair of numbers ("12" in the figure), then press **3** or **9** to set the value, and so on.



- Press **enter** to confirm (the cursor is no longer displayed under the numbers).




- Press **esc** several times until the "Main View" displays.



Acquisition range

Press **esc** several times to display the "Main Menu" if one of the menu continues to display.


- Select Menu 7-Programming (as explained in the previous paragraph), press **2**, select 2-Users Parameters, then press **enter**.



- The display shows the acquisition range. To change the displayed values, press **enter** (to display symbol <), then **4** or **2** to change them. Press **enter** to confirm.



- Press **esc** several times to display the "Main View".




Automatic configuration of the network

Before using this procedure, it is essential to check the following:


1. Electric wiring of probes; power supply; and serial line (remember to connect the 120Ω $\frac{1}{4}$ W terminal resistor)
2. Numerical addresses assigned to modules (parameters FAA and dEA) and alarm parameters
3. The presence of EWTV modules: assignment of probes present (P1P, P2P, P3P) and alarms parameters (HAL, LAL, ..delay time)

Press **esc** several times until "Main View" displays, if one of the menus continues to display:

- From the "Main View", press **↓** until Menu 8 – Setup displays:




- Press **enter** to open the menus. As soon as the password prompt displays, press Enter 5 times, then press it one more time to confirm.




- Press **↓** until Menu 2-Network Configuration displays.



- Press Enter to display Network Configuration. Press **enter** once more to display 1-Self-recognition. The procedure may require a few minutes to complete.



- At the end of the procedure, the following displays:



- To verify if all the devices have been correctly detected, open the Edit menu by performing the operations shown in the figure:



- Press **enter**. The display shows the first device detected in the family-address order (in the example F= 0-A=1, where F=FAA and d=dEA controller attribute). Then, press **↑** or **↓** to scroll the list.




Checking the presence of drivers –Assigning a name to controllers


- In the screen shown in the figure, select the desired controller by pressing . The display shows the first item (version). Press or until Driver Presence displays. The controller is correctly managed if the latter screen displays "Yes". If "NO" is displayed, you will need to add the driver with the "Configuration Tool".




- In the Presence Driver screen, press or until "Device Name" displays. Press to make the change (the cursor displays under the first letter).



- Press or to scroll the letters until the desired one displays. Press to highlight the second letter or to change it, etc....




- Press Enter to confirm (and display the cursor). Then, press to select another controller (using or) or press several times to quit the programming mode.




Starting/stopping recordings

Press several times until "Main View" displays, if one of the menus continues to display:


- In the "Main View", select 1 – Functions, as shown in the following figures:



- As soon as Functions displays, press Enter following the instructions below. Recording is enabled if the "Rec" LED switches on.



- To stop the recording, perform the operations shown in the figure:



This procedure completes the basic start-up of TelevisCompact. The procedures for the selection of menus and parameters described above applies also to other settings. For more information on these settings (connection of the modem, fax, sms, printer, etc.), see the User Manual on the CD-ROM.

DISCLAIMER

This document is the exclusive property of Eliwell and may not be reproduced or circulated unless expressly authorized by Eliwell. Although Eliwell has done everything possible to guarantee the accuracy of this document, it declines any responsibility for damage arising from its use. The same applies to any person or company involved in preparing and writing this document.

Eliwell reserves the right to make changes or improvements at any time without notice.



Eliwell Controls s.r.l.

Via dell'Industria, 15 • Zona Industriale Paludi • 32010 Pieve d'Alpago (BL) ITALY

Telephone +39 0437 986 111 • Facsimile +39 0437 989 066

Technical helpline +39 0437 986 300 • E-mail techsuppeliwell@invensyscontrols.com

www.eliwell.it

